




CASE Drives zu ASM105S/115S, AVM105S/115S  
 CASE Drives pour ASM105S/115S, AVM105S/115S  
 CASE Drives for ASM105S/115S, AVM105S/115S  
 CASE Drives per ASM105S/115S, AVM105S/115S  
 CASE Drives para ASM105S/115S, AVM105S/115S  
 CASE Drives zu ASM105S/115S, AVM105S/115S  
 CASE Drives zu ASM105S/115S, AVM105S/115S

Montagevorschrift  
 Instruction de montage  
 Fitting instructions  
 Istruzioni di montaggio  
 Instrucciones de montaje  
 Monteringsanvisning  
 Montagevoorschrift

Installationsanweisung für die Fachkraft / Monteur  
 Conseils d'installation pour le spécialiste / monteur  
 Guidelines for the technician / fitter  
 Informazioni per il personale specializzato di montaggio  
 Instrucciones para el especialista del ramo / montador  
 Installatietip voor de vakman / monteur  
 Installationsinstruktion för installatör / montör

Für den Einsatz in üblicher Umgebung  
 Pour usage dans un environnement normal  
 For use in normal environments  
 Per impiego in ambiente usuale  
 Para el uso en ambiente normal  
 För användning i normal miljö  
 Voor toepassing in normale omgeving





Dokument aufbewahren/Ce document est à conserver/Retain this document/Conservare il documento/Guardar el documento/  
Spara dokumentationen/Document bewaren

© Sauter AG CH-4016 Basel (Schweiz)  
Tel. +41 61 - 695 55 55 Fax +41 61 - 695 55 10

[Http://www.sauter-controls.com](http://www.sauter-controls.com)  
e-mail: [info@sauter-controls.com](mailto:info@sauter-controls.com)

0506101033 B  
Printed in Switzerland